



ngth	L IN(MM)	S IN(MM)	F IN(MM)	Approx Weight LB(KG)	
	56.60	28X1	54.10	21	
	(1438)	(711)	(1374)	(10)	
	96.60	96.60 56X1 94.10		31	
	(2454)	(1422)	(2390)	(14)	
	136.60 80X1 134.10		134.10	41	
	(3470)	(2032)	(3406)	(19)	
	176.60	64X2	174.10	51	
	(4486)	(1626)	(4422)	(23)	
	216.60	78X2	214.10	62	
	(5502)	(1981)	(5438)	(28)	
	256.60	92X2	254.10	71	
	(6518)	(2337)	(6454)	(32)	
	296.60	106X2	294.10	81	
	(7534)	(2692)	(7470)	(37)	
	J				

			VERNA, GOA INDIA			
RAWN BY:	KR	DRAWING DESCRIPTION:		DRAWING NO).:	REV.:
TE:	-	MODEL – 40E100 MEMBRANE	HOUSING	51801	5	R
IECKED BY:	MD	CUSTOMER NAME:		VESSEL MOD	EL:	
TE:	-	-		40E	100	
PROVED BY	: SS	PROJECT NAME:			TOTAL	QTY:
TE:	-	-			-	-
N NO. :	6123	CUSTOMER P.O.#:	SIZE:	SCALE:	PAGE	NO.:
TE:	05JUL22	-	A3	NONE	01 0	F 02

RATING:

DESIGN PRESSURE	
	(6.90 Mpa
MAX. OPERATING TEMP	120°F
	(49°C
MIN. OPERATING TEMP	20°l
	(-7°C)
FACTORY TEST PRESSURE	
	1500 / 1100 PS
	(10.34 Mpa) / (7.58 MPa)
BURST PRESSURE	6000 PSI
	(41.37 MPa)

INTENDED USE:

The CodeLine Model 40E100 Fiberglass RO Pressure Vessel is designed for continuous, long term use as housing for reverse osmosis membrane elements to desalt typical sea waters at pressures up to 1000 psi. Any make of four-inch nominal diameter spiral-wound element is easily accommodated; the appropriate interfacing hardware for the element specified is furnished with the vessel.

The CodeLine Model 40E100 is designed in accordance with the engineering standards of the Boiler and Pressure Vessel Code of the American Society of Mechanical Engineers (ASME Code) Section X Edition 2021. F/C port, Bearing plate and Quick release spiral ring are designed as per Section VIII Division I Edition 2021. At small additional cost, vessels can be inspected during construction by an ASME Authorized inspector and ASME Code stamped.

The CodeLine Model 40E100 must be installed, operated and maintained in accordance with the listed precautions and good industrial practice to assure safe operation over a long service life.

The high performance reinforced plastic shell must be allowed to expand under pressure; undue restraint at support points or piping connections can cause leaks to develop in the shell. The end closure, incorporating close fitting, interlocking metal components, must be kept dry and free of corrosion; deterioration can lead to catastrophic mechanical failure of the head.

The end closures, incorporating close-fitting, interlocking metal components, must be kept dry and free of corrosion; deterioration can lead to catastrophic mechanical failure of the heads.

Pentair will assist the purchaser in determining the suitability of this standard vessel for their specific operating conditions. The final determination however, including evaluation of the standard material of construction for compatibility with the specific corrosive environment, shall be the responsibility of the purchaser.

Specifications are subject to change without notice.

PRECAUTIONS:

- DO...read, understand and follow all instructions; failure to take every precaution will void warranty and may result in vessel failure
- PF DO...mount the shell on horizontal members at span "S" using complaint vessel supports furnished; tighten hold down straps just snug
 SI DO...provide overpressure protection for vessel
 - set at not more than 105% of design pressure DO...inspect end closures regularly; replace components that have deteriorated and correct causes of corrosion
 - DO NOT... make rigid piping connections to ports or clamp vessel in any way that resists growth of fiberglass shell under pressure; Δ DIA = 0.02 in. (0.5mm) and Δ L = 0.2 in. (5mm) for a length code –6 vessel
 - DO NOT... hang piping manifolds from ports or use vessel in any way to support other components;
 - DO NOT... operate vessel at pressures and temperatures in excess of its rating
 - DO NOT... operate vessel without permeate ports internally connected with a complete set of elements and interconnecting hardware
 - DO NOT... operate vessel with permeate pressure in excess of 125 psi at 120°F (0.86 MPa @ 49°C)
 - DO NOT... overtighten the connection to the permeate port (hand-tighten plus one-quarter turn, check for leaks)
 - DO NOT... tolerate leaks or allow end closures to be routinely wetted in any way
 - DO NOT... pressurize vessel until doublechecking to verify that the retaining ring is completely inside the groove
 - DO NOT... work on any component until first verifying that pressure is relieved from vessel
 - DO NOT... operate outside the pH range 3-11

For complete information on proper use of this vessel please refer to the 40E100 USER'S GUIDE Bulletin 526005.

NOTE Spiral Retaining Ring Removal Tool (50303) Recommended to open and close vessel.

ORDERING:

Using the chart below, please check the features you require and fax them with your purchase order to our customer service department for expedited processing.

For optional materials and/or features not listed below, please consult factory for pricing and availability.

VESSEL LENGTH CODE – please check one

MEMBRANE BRAND AND MODEL – please check one and fill in information

Please supply adapters for the following membrane brand and specific model Brand Model

box below

Membrane brand and model information is not available, but will be supplied to Pentair on or before the following date _____/____/_____

Please note that we require your

membrane brand and model number

when ordering. If this information is not

initially available, you may provide it at

a later date by checking the appropriate

CERTIFICATION REQUIRED- please check one

- □ ASME Stamped and National Board Registered.
- In compliance with the ASME Sec. X but not Code Stamped.
- CE Marked.

PERMEATE PORT

- □ 47469- Hub + Nipple assembly, Engineering Thermoplastic.
- □ 196315- Single piece Engineering Thermoplastic.

EXTERIOR FINISH - please check one

- □ White high-gloss RAL 9003 polyurethane coating.
- □ Optional colors are available for 50 or more vessels per order. Call factory for pricing details.

MATERIAL AND PORT CONFIGURATIONS OPTIONS- please check one

- □ All materials and port configurations as per drawing 518015 on the first page.
- □ Feed/Concentrate port, ³/₄" IPS Grooved (P/N 47473)

CAUTION: EYE PROTECTION SHOULD BE WORN WHEN REMOVING OR INSTALLING RETAINING RINGS. KEEP FINGERS CLEAR FROM RETAINING RING WHILE INSTALLING LAST OF TWO TURNS. RING MAY SNAP INTO POSITION POSSIBLY PINCHING FINGERS.

THIS DOCUMENT AND THE INFORMATION CONTAINED HEREIN, ARE THE CONFIDENTIAL AND PROPRIETARY INFORMATION OF PENTAIR INDIA PVT. LTD. PENTAIR INDIA PVT. LTD. IS THE SOLE OWNER OF THE INFORMATION AND PROCESSES DEFINED HEREIN. THIS DOCUMENT, AND THE INFORMATION CONTAINED, MAY NOT BE DISCLOSED, REPRODUCED, DUPLICATED, USED, SOLD, PUBLISHED, COMMUNICATED OR OTHERWISE DISTRIBUTED, IN WHOLE OR IN PART, FOR ANY PURPOSE WITHOUT THE EXPRESS WRITTEN CONSENT OF PENTAIR INDIA PVT. LTD. THIS DOCUMENT AND ANY COPIES, IN ALL APPLICABLE FORMATS, SHALL BE RETURNED TO PENTAIR INDIA PVT. LTD. UPON REQUEST.

ALL INDICATED PENTAIR TRADEMARKS AND LOGOS ARE PROPERTY OF PENTAIR. THIRD PARTY REGISTERED AND UNREGISTERED TRADEMARKS AND LOGOS ARE PROPERTY OF THEIR RESPECTIVE OWNERS. BECAUSE WE ARE CONTINUOSLY IMPROVING OUR PRODUCTS AND SERVICES, PENTAIR RESERVES THE RIGHT TO CHANGE SPECIFICATIONS WITHOUT PRIOR NOTICE. PENTAIR IS AN EQUAL OPPORTUNITY EMPLOYER.

DF DA CF DA AP DA

C 2021 Pentair, All Rights Reserved.

				VERNA, GO India	A	
RAWN BY:	KR	DRAWING DESCRIPTION:		DRAWING N0.:		REV.:
TE:	-	MODEL - 40E100 MEMBRANE HOUSING		518015		R
ECKED BY:	MD	CUSTOMER NAME:		VESSEL MODEL:		
TE:	-	-		40E	100	
PROVED BY:	SS	PROJECT NAME:			TOTAL QTY:	
TE:	-	-			-	-
N NO. :	6123	CUSTOMER P.O.#:	SIZE:	SCALE:	PAGE	NO.:
TE:	05JUL22	-	A3	NONE	02 O	F 02
