

©2021 Pentair. All Rights Reserved.

1.5" IPS PIPE GROOVED END			
NO. OF PORTS PORT LOCATION VESSEL (
DashLPSApproLengthIN(MM)IN(MM)IN(MM)WeigLB(K	ght		
-1 59.15 47 23X1 46 (1502) (1194) (584) (21			
-2 99.15 87 56X1 55 (2518) (2210) (1422) (25			
-3 139.15 127 80X1 64			
(3534) (3226) (2032) (29 -4 179.15 167 64X2 73			
(4550) (4242) (1626) (33	-		
Image: PORT PRESSURE -5 219.15 207 78X2 82 0,000 (5566) (5566) (5258) (1981) (37)			
-6 259.15 247 92X2 90	-		
(6582) (6274) (2337) (41	,		
-7 299.15 287 106X2 99 (7598) (7290) (2692) (45			
-8 339.15 327 120X2 108 (8614) (8306) (3048) (49	3		
PENTAIR VERNA, GOA CODELINE® ECOLINE INDIA DRAWIN BY: RA DRAWING DESCRIPTION: DRAWING NO.:			
CHECKED BY: KPS CUSTOMER NAME: VESSEL MODEL:			
DATE: 15/09/21 -	L QTY: -		
ECN NO.: 5902 CUSTOMER P.O.#: SIZE: SCALE: PAGE DATE: 16/12/21 - A3 NONE 01 C			

RATING:

DESIGN PRESSURE	
	(49°C)
MAX. OPERATING TEMP	120°F
	(49°C)
MIN. OPERATING TEMP	20°F
	(-7°C)
FACTORY TEST PRESSURE	
	(3.10 MPa)
QUALIFICATION PRESSURE	1800 PSI
	(12.4 MPa)

INTENDED USE:

The EcoLine 80-300 Non Coded Fiberglass RO Pressure Vessel is designed for continuous, long term use as housing for reverse osmosis membrane elements to desalt typical brackish waters at pressures up to 300 psi. Any make of eight-inch nominal diameter spiral-wound element is easily accommodated; the appropriate interfacing hardware for the element specified is furnished with the vessel.

The Shell of EcoLine 80-300 Non Coded vessel is designed in accordance with the engineering standards of the Boiler and Pressure Vessel Code of the American Society of Mechanical Engineers (ASME) as per ASME Section X Edition 2021. F/C port and Quick release spiral ring are designed as per ASME Section VIII Division I Edition 2021.

The EcoLine 80-300 Non Coded vessel must be installed operated and maintained in accordance with the listed precautions and good industrial practice to assure safe operation over a long service life.

The high performance Filament wound FRP shell must be allowed to expand under pressure; undue restraint at support points or piping connections can cause leaks to develop in the shell. This side-ported vessel requires special precautions in mounting and connection to piping so that the vessel will not be subjected to excessive stress due to bending moments acting at the side openings in the fiberglass shell. The end closure, incorporating close fitting, interlocking metal components, must be kept dry and free of corrosion; deterioration can lead to catastrophic mechanical failure of the head.

Pentair will assist the purchaser in determining the suitability of this standard vessel for their specific operating conditions. The final determination however, including evaluation of the standard material of construction for compatibility with the specific corrosive environment, shall be the responsibility of the purchaser. Alternate materials with enhanced corrosion resistance are available on special order.

Specifications are subject to change without notice.

PRECAUTIONS:

- DO...read, understand and follow all instructions; failure to take every precaution will void warranty and may result in vessel failure
- DO...mount the shell on horizontal members at span "S" using compliant vessel supports furnished; tighten hold down straps just
- DO...align and center side ports with the manifold header. Correct, causes of misalignment in a row of vessels connected to the same header
- DO...use flexible type grooved-end pipe couplings, Victaulic® Style 77 or equal, at side ports; allow full, 0.125 inch gap between port and piping, and position piping to maximize flexibility of connection.
- DO...provide flexibility in, and support for piping manifolds so that vessel can grow in length under pressure without undue restraint; provide additional flexible joints in large pipes leading to manifold header.
- DO...provide overpressure protection for vessel set at not more than 105% of design pressure
- DO...inspect end closures regularly; replace components that have deteriorated and correct causes of corrosion.
- DO...Lubricate seals Sparingly, Using non petroleum based lubricants, i.e. Glycerin or suitable lubricants.
- DO NOT...work on any component until first verifying that pressure is relieved from vessel
- DO NOT...make rigid piping connections to ports or clamp vessel in any way that resists growth of fiberglass shell under pressure; *** $\Delta DIA = 0.015$ in. (0.4mm) and
 - *** $\Delta L = 0.2$ in. (6mm) for a length code -8 vessel
- DO NOT... hang piping manifolds from ports or use vessel in any way to support other components
- DO NOT., tighten Permeate Port connection more than one turn past hand tight
- DO NOT ... operate vessel without connecting both Permeate Ports internally to complete set of elements or otherwise plug ports internally so that external piping connection is not subjected to feed pressure
- DO NOT...install Spacer on downstream end of vessel
- DO NOT...operate vessel without Thrust Cone installed downstream
- DO NOT...pressurize vessel until double-checking to verify that the Locking Ring is in place and fully seated.
- DO NOT...operate vessel at pressure and temperature in excess of its rating.
- DO NOT...operate vessel with permeate pressure in excess of 125 psi at 120°F (0.86 MPa at 49°C).
- DO NOT ... tolerate leaks or allow end closures to be routinely wetted in any way
- DO NOT...operate outside the pH range of 3-11.

ORDERING:

Using the chart below, please check the features you require and fax them with your purchase order to our customer service department for further processing.

For optional materials and / or feature not listed below, please consult the factory for pricing and availability

VESSEL LENGTH CODE - please check one

MEMBRANE BRAND AND MODEL - please check one and fill in information

- Please supply adapters for the following membrane brand and specific model Brand Model
- □ Membrane brand and model information is not currently available, but will be supplied to Pentair Water on or before the following date. / /

CERTIFICATION REQUIRED

- CE Marked.
- □ Standard Certified by Pentair.

MATERIAL AND PORT CONFIGURATIONS OPTIONS

□ Standard: All materials and port configurations as per drawing 99196 on the previous page.

FEED PORT CONFIGURATION

□ Standard – 1¹/₂" IPS pipe, grooved ends, with ports in-line. (1D5D).

Please fill out your feed port configuration in the space below. List port location first, followed by port size for each choice.

Serial number end Opposite end PORT SIZE CODE D 1¹/₂" GROOVED END

For complete information on proper use of the vessel Please refer to the EcoLine Series. USER'S GUIDE 98244.

THIS DOCUMENT AND THE INFORMATION CONTAINED HEREIN, ARE THE CONFIDENTIAL AND PROPRIETARY INFORMATION OF PENTAIR INDIA PVT. LTD. PENTAIR INDIA PVT. LTD. IS THE SOLE OWNER OF THE INFORMATION AND PROCESSES DEFINED HEREIN. THIS DOCUMENT AND THE INFORMATION CONTAINED, MAY NOT BE DISCLOSED, REPRODUCED, DUPLICATED, USED, SOLD PUBLISHED, COMMUNICATED OR OTHERWISE DISTRIBUTED, IN WHOLE OR IN PART, FOR ANY PURPOSE WITHOUT THE EXPRESS WRITTEN CONSENT OF PENTAIR INDIA PVT. LTD. THIS DOCUMENT AND ANY COPIES, IN ALL APPLICABLE FORMATS, SHALL BE RETURNED TO PENTAIR INDIA PVT. LTD. UPON REQUEST.

ALL INDICATED PENTAIR TRADEMARKS AND LOGOS ARE PROPERTY OF PENTAIR.THIRD PARTY REGISTERED AND UNREGISTERED TRADEMARKS AND LOGOS ARE PROPERTY OF THEIR RESPECTIVE OWNERS.BECAUSE WE ARE CONTINUOSLY IMPROVING OUR PRODUCTS AND SERVICES, PENTAIR RESERVES THE RIGHT TO CHANGE SPECIFICATIONS WITHOUT PRIOR NOTICE. PENTAIR IS AN EQUAL OPPORTUNITY EMPLOYER

C2021 Pentair. All Rights Reserved.

